

A FLASH Bootloader for PIC16 and PIC18 Devices

*Author: Ross M. Fosler and
Rodger Richey
Microchip Technology Inc.*

INTRODUCTION

Among the many features built into Microchip's Enhanced FLASH Microcontroller devices is the capability of the program memory to self-program. This very useful feature has been deliberately included to give the user the ability to perform bootloading operations. Devices like the PIC18F452 are designed with a designated "boot block", a small section of protectable program memory allocated specifically for bootload firmware.


This application note demonstrates a very powerful bootloader implementation for the PIC16F87XA and PIC18F families of microcontrollers. The coding for the two device families is slightly different; however, the functionality is essentially the same. The goals of this implementation stress a maximum performance and functionality, while requiring a minimum of code space.

FIRMWARE

Basic Operation

Figure 1 summarizes the essential firmware design of the bootloader. Data is received through the USART module, configured in Asynchronous mode for compatibility with RS-232 and passed through the transmit/receive engine. The engine filters and parses the data, storing the information into a data buffer in RAM. The command interpreter evaluates the command information within the buffer to determine what should be done (i.e., Is the data written into a memory unit? Is data read from a memory unit? Does the firmware version need to be read?). Once the operation is performed, data is passed back to the transmit/receive engine to be transmitted back to the source, closing the software flow control loop.

FIGURE 1: BOOTLOADER FUNCTIONAL BLOCK DIAGRAM



COMMUNICATIONS

The microcontroller's USART module is used to receive and transmit data; it is configured as a UART to be compatible with RS-232 communications. The device can be set up in an application to bootload from a computer through its standard serial interface. The following communications settings are used:

- 8 data bits
- No parity
- 1 STOP bit

The baud rate setting is variable depending on the application. Baud rate selection is discussed later.

AN851


THE RECEIVE/TRANSMIT BUFFER

All data is moved through a buffer (referred to as the Receive/Transmit Buffer). The buffer is a maximum of 255 bytes deep. This is the maximum packet length supported by the protocol. However, some devices may not support the largest packet size due to memory limitations. Figure 2 shows an example of the mapping of the buffer within the PIC18F452.

Note: The actual packet length supported by a particular device depends on the size of its data memory.

A useful feature of the receive/transmit buffer is that it retains its memory between packets, thus allowing very fast repeat and replication operations. That is, if an empty packet is sent, the data currently in memory will be executed as if it were just received.

FIGURE 2: DATA MEMORY USAGE ON THE PIC18F452



COMMAND INTERPRETER

The command interpreter decodes and executes ten different commands, seven base commands and three special commands. A complete list of the commands is provided in Appendix A. The base commands allow for read, write, and erase operations on all types of non-volatile memory. The other three commands are for special operations, such as repeating the last command, replicating the data, and resetting the device.


Note that the PIC18F devices have greater access to, and control of, memory than PIC16F devices. For example, PIC16F devices do not have access to the configuration memory, thus they do not use the configuration commands. Therefore, not all instructions are available in the PIC16F bootloader.

Memory Organization

PROGRAM MEMORY USAGE


Currently, PIC18F devices reserve the first 512 bytes of Program Memory as the boot block. Future devices may expand this, depending on application requirements for these devices. However, this bootloader is designed to occupy the current designated boot block of 512 bytes (or 256 words) of memory. Figure 3 shows a memory map of the PIC18F452. The boot area can be code protected to prevent accidental overwriting of the boot program.

FIGURE 3: PROGRAM MEMORY MAP OF THE PIC18F452



PIC16F87XA enhanced microcontrollers are designed to use the first 256 words of program memory. Figure 4 shows the memory map of the PIC16F877A. Like the PIC18F452 and other PIC18F devices, the boot area can be write protected to prevent accidental overwriting of the boot program.

FIGURE 4: PROGRAM MEMORY MAP OF THE PIC16F877A



REMAPPED VECTORS


Since the hardware RESET and interrupt vectors lie within the boot area and cannot be edited if the block is protected, they are remapped through software to the nearest parallel location outside the boot block. Remapping is simply a branch for interrupts, so PIC18F users should note an additional latency of 2 instruction cycles to handle interrupts. Upon RESET, there are some boot condition checks, so the RESET latency is an additional 10 instruction cycles (as seen in the example source code).

For PIC16F87XA devices, the interrupt latency is an additional 9 instruction cycles on top of the 3 to 4 normally experienced; the RESET latency is 18 instruction cycles. This additional latency comes from saving device context data in shared memory. The example code uses locations 7Dh, 7Eh, and 7Fh to store the PCLATH, STATUS, and W registers, respectively. The source code can be changed, but the saved data must remain in the shared memory area.

DATA MEMORY USAGE

The last location in data memory of the device (Figure 5) is reserved as a non-volatile Boot mode flag. This location contains FFh by default, which indicates Boot mode. Any other value in this location indicates normal Execution mode.

FIGURE 5: DATA MEMORY MAP



Communication Protocol

The bootloader employs a basic communication protocol that is robust, simple to use, and easy to implement.

PACKET FORMAT

All data that is transmitted to or from the device follows the basic packet format:

```
<STX><STX> [ <DATA><DATA> . . . ] <CHKSUM><ETX>
```

where each <...> represents a byte and [...] represents the data field.

The start of a packet is indicated by two 'Start of TeXt' control characters (<STX>), and is terminated by a single 'End of TeXt' control character (<ETX>). The last byte before the <ETX> is always a checksum, which is the two's complement of the Least Significant Byte of the sum of all data bytes.

The data field is limited to 255 data bytes. If more bytes are received, then the packet is ignored until the next <STX> pair is received.

Note: Although the protocol supports 255 bytes of data, the specific device that contains the bootloader firmware may have a sufficiently large data memory to support the largest packet size. Refer to the data sheet for the particular device for more information.

CONTROL CHARACTERS

There are three control characters that have special meaning. Two of them, <STX> and <ETX>, are introduced above. The last character not shown is the 'Data Link Escape', <DLE>. Table 1 provides a summary of the three control characters.

TABLE 1: CONTROL CHARACTERS

Control	Value	Description
<STX>	0Fh	Start of TeXt
<ETX>	04h	End of TeXt
<DLE>	05h	Data Link Escape

AN851

The <DLE> is used to identify a value that could be interpreted in the data field as a control character. Within the data field, the bootloader will always accept the byte following a <DLE> as data, and will always send a <DLE> before any of the three control characters. For example, if a byte of value 0Fh is transmitted as part of the data field, rather than as the <STX> control character, the <DLE> character is inserted before the <STX>. This is called “byte stuffing”.

Note: Control characters are not considered data and are not included in the checksum.

COMMANDS

The data field for each packet contains one command and its associated data. The commands are detailed in Appendix A.

COMMAND RESPONSE LATENCY

Flow control is built into the protocol. Thus, for every received command (except RESET), there is a response. If there is no response, then one (or more) of the following has happened:


- the data was corrupted (bad checksum)
- the packet was never received
- the data field was too long
- RESET was executed

So how long do you wait before deciding a problem has occurred? The response latency (shown in Figure 6) is dependent on the amount of data sent, the command being executed, and the clock frequency.

For read commands, the latency is highly dependent on the clock frequency, and the size of the packet. For a small packet at high frequency, the response is almost immediate, typically on the order of a few microseconds. For large packets, the latency could be on the order of hundreds of microseconds.

In general, read commands require very little time compared to write commands. Write commands are mostly dependent on internally timed write cycles. For example, the typical write time required for a single EEPROM location is 4 ms. If the maximum packet size (250 bytes of writable data) was sent, the receive to transmit latency would be about 1 second.

FIGURE 6: RECEIVE TO TRANSMIT LATENCY



Automatic Baud Rate Detection

The bootloader is provided with an automatic baud rate detection algorithm that will detect most baud rates for most input clock frequencies (F_{OSC}). The algorithm determines the best value for the Baud Rate Generator and then loads the SPBRG register on the microcontroller with the determined value.

Note: Refer to the specific device data sheet for information about the USART module and its associated registers.

SYNCHRONIZING

The first <STX> in the protocol is the synchronization byte. It is used to match the device's baud rate to the source's baud rate. Thus, the device is synchronized to the source on every new packet.

Note: If a 'Start of TeXt' condition is received during the reception of a packet, then no synchronization occurs.

SELECTING F_{OSC} AND BAUD RATE

The recommended baud rate for this application is 9600 bps. This is the ideal rate for a device operating from 4 MHz, to the device's maximum operating frequency (40 MHz in most cases). Higher baud rates are possible, but degenerate conditions can occur.

There are a few clock frequency/standard baud rate combinations that lead to a degenerate baud rate selection during synchronization; under such conditions, the device will never synchronize to the source. Clock frequencies that avoid such degenerate conditions are given by the equation:

$$F_{OSC} = (1 \pm E)(X + 1)(16)(B)$$

where E is the error (typically 2%), X is the value for the SPBRG register, and B is the baud rate. A table of calculated clock oscillator ranges for most of the common baud rates is provided in Appendix B for quick reference.

BOOTING A DEVICE

Entering and Leaving Boot Mode

With the bootloader firmware loaded, there are two distinct modes of operation: *Boot Mode* and *User Mode*. The bootloader uses the last location of data memory to determine which mode to run in. A value of FFh indicates Boot mode. Any other value indicates User mode. Thus, a new part with its data memory not initialized will automatically enter Boot mode the first time.

To leave Boot mode, the last location must be changed to some value other than FFh. Then, a device RESET (hardware or software) is initiated. For PIC18F devices, the RESET command actually generates a true RESET via the RESET instruction (same as MCLR). Other than tying a port pin to MCLR, a true RESET is not possible in firmware on PIC16F87XA devices. Although the RESET command is supported, it only causes the PIC16F device to jump to the RESET vector; the registers used to perform bootload operations are not changed to their RESET states.

Reading/Writing/Erasing Program Memory

PIC18F

For the PIC18F devices, commands 1 through 3 support operations to FLASH program memory. Read operations occur at the byte level. Write operations are performed on multiples of 8 bytes (one block). Erase operations are performed on 64 bytes (one row).

When writing program memory on a PIC18F device, the memory should be erased. The default operation is: bits can only be cleared when written to. An erase operation is the only action that can be used to set bits in program memory. Thus, if the bootloader protection bits are not setup in the configuration bytes, operations on memory from 000h to 1FFh could partially, or completely disable the bootloader firmware.

User IDs (starting at address 200000h) are considered to be part of program memory and are written and erased like normal FLASH program memory. The Device ID (addresses 3FFFEh and 3FFFFh) is also considered program memory. While they can be accessed, however, they are read only and cannot be altered.

PIC16F

The PIC16F87XA devices support reading and writing to program memory. Commands 1 and 2 support operations to FLASH program memory. Read operations occur at the word level (2 bytes). Write operations are performed on multiples of 4 words (8 bytes). Since write operations are erase-before-write, the erase command is not supported. The bootloader area, from 000h to 0FFh, should be write protected to prevent overwriting itself.

Neither the User ID nor the Device ID locations are accessible during normal operation on the PIC16 architecture; therefore, these areas can neither be read nor written.

Reading/Writing Data Memory

Data memory is read or written one byte at a time, through commands 4 and 5. Since it is not actually mapped to the normal FLASH memory space, the address starts at 000h and continues to the end of EEDATA memory.

Note that the last location of the data memory is used as a boot flag. Writing anything other than FFh to the last location indicates normal code execution.

Configuration Bits

PIC18F

PIC18F devices allow access to the device configuration bits (addresses starting at 300000h) during normal operation. In the bootloader, commands 6 and 7 provide this access. Data is read one byte at a time and, unlike program memory, is written one byte at a time. Since configuration bits are automatically erased before being written, there is no erase command for configuration memory.

Having access to configuration settings is very powerful; it is also potentially very dangerous. For example, assume that the system is designed to run in HS mode, with a 20 MHz crystal. If the bootloader changes the oscillator setting to LP mode, the system will cease to function — including the bootloader! Basically, the system has been killed by improperly changing one bit.

It is also important to note some configuration bits are single direction bits in Normal mode; they can only be changed to one state, and cannot be changed back. The code protection bits in Configuration Registers 5L and 5H are a good example. If any type of code protection is enabled for a block, it cannot be disabled without a device programmer. Essentially, the bootloader cannot reverse code protection.

PIC16F

The configuration memory is not accessible during normal operation on the PIC16 architecture; therefore, this area can neither be read nor written.

WRITING CODE

The bootloader operates as a separate entity, which means that an application can be developed with very little concern about what the bootloader is doing. This is as it should be; the bootloader should be dormant code until an event initiates a boot operation. Under ideal circumstances, bootloader code should never be running during an application's intended normal operation.

When developing an application with a resident bootloader, some basic principles must be kept in mind:

Writing in Assembly

When writing in assembly, the boot block and new vectors must be considered. For modular code, this is generally just a matter of changing the linker script file for the project. An example is given in Appendix D. If an absolute address is assigned to a code section, the address must point somewhere above the boot block.

For those who write absolute assembly, all that is necessary is to remember that for PIC18F devices, the new RESET vector is at 200h, and the interrupt vectors are at 208h and 218h. For PIC16F87XA devices, the RESET vector is at 100h and the interrupt vector is at 104h. No code, except the bootloader, should reside in the boot block.

Writing in C

When using the MPLAB® C18 C compiler to develop PIC18F firmware for an application, the standard start-up object (`c018.o` or `c018i.o`) must be rebuilt with the new RESET vector. Like modular assembly, the linker file must be changed to incorporate the protected boot block and new vectors. Appendix D shows an example linker file.

For users of other compilers, for either PIC16F87XA or PIC18F devices, check with the compiler's software user guide to determine how to change the start-up code and vectors.

Bootloader Re-Entry

If the need exists to re-enter Boot mode from the application (and it usually does), the last location of the data memory must be set to FFh. The code in Example 1 demonstrates how this might be done in an application on a PIC18F device. Since the bootloader assumes RESET conditions, a RESET instruction should be initiated after setting the last location.

EXAMPLE 1: SETTING THE LAST LOCATION OF THE DATA MEMORY

```
setf    EEADR      ; Point to the last byte
setf    EEADRH
setf    EEDATA     ; Bootmode control byte
movlw   b'00000100 ; Setup for EEData
movwf   EECON1
movlw   0x55       ; Unlock
movwf   EECON2
movlw   0xAA
movwf   EECON2
bsf     EECON1, WR ; Start the write
nop
btfsc  EECON1, WR ; Wait
bra     $ - 2
reset
```

Debugging

For most situations, it is not necessary to have the bootloader firmware in memory to do debugging of an application with either the MPLAB ICD 2 or ICE devices. However, branch statements must be inserted at the hardware vectors to get to the new designated vectors. It may also be useful to have the start-up timing match exactly to the bootloader entry. When development of the application is finished, either remove the branches and rebuild the project, or export only the memory above the boot block. This code can then be distributed to those who are updating their firmware.


EXAMPLE SOFTWARE

The Microchip PIC16/PIC18 Quick Programmer is a simple application designed to run on IBM® compatible desktop computers; it is provided with the FLASH boot-loader to perform basic programming operations. The Quick Programmer should be used as a starting point for users to create their own programming applications.

Selecting a Device

The first thing to appear after launching `P1618QP.EXE` is the device selection dialog box (Figure 7). This floating box gives the user the option to manually select a device to communicate with, from a drop-down menu. For PIC18F devices, the automatic detection feature is available. PIC16F devices must be manually selected.

FIGURE 7: DEVICE SELECTION



The Main Toolbar

The main program menu (Figure 8) appears as a floating toolbar over any other running applications, and not as its own window. It provides some basic commands, as well as information from the device.

CONNECTING TO A DEVICE

Before anything can happen, communications to the attached device must be opened. This is done with the Connect to Device button. If automatic detection was selected, then the software will read the device ID and try to match it with device information provided in the `P1618QP.INI`. If a device is manually selected, then

the settings for that particular device are forced. In either event, the device identity is shown in the Device Identifier area.

Note that PIC16F devices cannot access device ID memory during normal execution; thus, PIC16F devices must be manually selected.

READING/WRITING/ERASING

The Read Device, Write To Device and Erase Device buttons are used for reading, writing, and erasing the attached device. The Read Device button tells the program to read the entire device. The Write to Device button writes only the data imported from a HEX file. The Erase Device button erases the entire device; the command is not available for PIC16F devices.

IMPORTING/EXPORTING HEX FILES

Basic file import and export operations are available. The Microchip PIC16/PIC18 Quick Programmer uses formatted text files to store data, rather than large chunks of memory. Importing converts the HEX file into a formatted text file; exporting does the opposite. The program uses the formatted text file for storage and display.

When importing a file, always be certain that the HEX file is padded and aligned to a 16-byte boundary. MPLAB IDE automatically pads to 16 bytes when an integer multiple of 16 bytes of data is selected on a 16-byte boundary when using the Export feature.


VIEWING/CLEARING MEMORY

The View Data and Clear Data buttons allow the user to view or clear the data that was imported, or read from the device. The program does not include any type of text viewer, and uses the viewer specified in the `PIC1618QP.INI` file. By default, the viewer used in Windows® is Notepad.

RUN MODE

When the desired data is loaded onto the device, selecting this button will put the device into User mode, by writing 00h to the last location of the data memory.

FIGURE 8: QUICK PROGRAMMER TOOL BAR



AN851


PORT AND BAUD RATE SELECTION

The default serial port and its baud rate (COM1, 9600) are specified in the PIC1618QP.INI file. The user may change these settings while the application is running by right-click on either the port, or baud rate identifier. A menu of valid options that the user may select from (COM ports or baud rates) will appear.

Menu Options

Right-clicking on the status or the toolbar displays a pop-up menu that gives access to some settings and advanced operations. Figure 9 shows the menu options available.

FIGURE 9: MENU OPTIONS



DEVICE SELECTOR

This menu option gives the user the ability to re-select a device, or select a new device (see "Selecting a Device" and Figure 7).


MEMORY ACCESS

The memory types are either checked or unchecked to determine access. As an example, Figure 9 shows access to FLASH program memory and data memory, while access to CONFIG memory and User ID memory is ignored. Since normal access to CONFIG and User ID memory is not allowed in PIC16F devices, these options are not available when a PIC16F device is selected.

SEND CONFIG

The check access for CONFIG in Figure 9 is for read operations only, due to the danger imposed by writing all configuration bits sequentially. The "Send Config Settings" dialog box (Figure 10) is used to actually write configuration register settings.

FIGURE 10: SETTING CONFIG BITS



Selecting a configuration register label from the Address list box will automatically load the current data at that address. The value in the Data field can be edited, then written back to the device by clicking on the Send button.

DIFFERENCES BETWEEN THE PIC16F87XA AND PIC18F BOOTLOADERS

Because of architectural enhancements in PIC18F devices, there are two main differences between the PIC16F87XA and PIC18F bootloaders.

1. The PIC16F87XA bootloader does not support the following commands:
 - Erase FLASH
 - Read CONFIG
 - Write CONFIG
2. The RESET command is only partially supported. When the microcontroller receives a RESET command, it executes a `goto 0x0000`. This is not a true RESET of the microcontroller. The following registers are not set to their default RESET states on execution of the command:
 - EEADR
 - EEADRH
 - EECON1
 - OPTION_REG
 - RCSTA
 - STATUS
 - TXSTA
 - EEDATA
 - EEDATH
 - FSR
 - PIR1
 - SPBRG
 - TRISC

This is particularly important when leaving Boot mode via a software RESET. The application software must be prepared to accept non RESET values in the registers listed above. If RESET conditions are necessary, then the listed registers should be initialized in the application code. The alternative is to always perform a hardware RESET (\overline{MCLR}) after completing a bootstrap operation.

APPENDIX A: BOOTLOADER COMMANDS

TABLE A-1: BOOTLOADER COMMANDS

Name	Number	Description	Command Device [data field]	Response [data field]	PIC18F	PIC16F
RESET	ANY	Reset the Device	[<COM><0x00>]	none	X	X
RD_VER	00h	Read Bootloader Version Information	[<0x00><0x02>]	[<0x00><0x02><VERL><VERH>]	X	X
RD_FLASH	01h	Read <LEN> bytes from Program Memory	[<0x01><LEN><ADDRL><ADDRH><ADDRU>]	[<0x01><LEN><ADDRL><ADDRH><ADDRU>... LEN bytes of Data...]	X	X
WT_FLASH	02h	Write <LEN> blocks to Program Memory	[<0x02><LEN><ADDRL><ADDRH><ADDRU>... LEN bytes of Data...]	[<0x02>]	X	X
ER_FLASH	03h	Erase <LEN> rows of Program Memory	[<0x03><LEN><ADDRL><ADDRH><ADDRU>]	[<0x03>]	X	
RD_EEDATA	04h	Read <LEN> bytes from EE Data Memory	[<0x04><LEN><ADDRL><ADDRH><0x00>]	[<0x04><LEN><ADDRL><ADDRH><0x00>... LEN bytes of Data...]	X	X
WT_EEDATA	05h	Write <LEN> bytes to EE Data Memory	[<0x05><LEN><ADDRL><ADDRH><0x00>... LEN bytes of Data...]	[<0x05>]	X	X
RD_CONFIG	06h	Read <LEN> bytes from Configuration Memory	[<0x06><LEN><ADDRL><0x00><0x30>]	[<0x06><LEN><ADDRL><0x00><0x30>... LEN bytes of Data...]	X	
WT_CONFIG	07h	Write <LEN> bytes to Configuration Memory	[<0x07><LEN><ADDRL><0x00><0x30>... LEN bytes of Data...]	[<0x07>]	X	
REPEAT	COM	Repeat last Command	[Empty data field]	Refer to the appropriate command response for the last command sent	X	X
REPLICATE	COM	Write old Buffer Data to another area	[<COM><LEN><ADDRL><ADDRH><ADDRU>] where <COM> is any write command	[<COM>]	X	X

AN851

APPENDIX B: Fosc vs. BAUD RATE FOR AUTO BAUD DETECTION

TABLE B-1: Fosc (MHz) FOR VARIOUS BAUD RATES (F(X,B), FOR $\pm 2\%$ ERROR)

SPBRG (X)	Baud Rate (B)											
	2400		9600		19200		38400		57600		115200	
	Low	High	Low	High	Low	High	Low	High	Low	High	Low	High
0	0.04	0.04	0.15	0.16	0.3	0.31	0.6	0.63	0.9	0.94	1.81	1.88
1	0.08	0.08	0.3	0.31	0.6	0.63	1.2	1.25	1.81	1.88	3.61	3.76
2	0.11	0.12	0.45	0.47	0.9	0.94	1.81	1.88	2.71	2.82	5.42	5.64
3	0.15	0.16	0.6	0.63	1.2	1.25	2.41	2.51	3.61	3.76	7.23	7.52
4	0.19	0.2	0.75	0.78	1.51	1.57	3.01	3.13	4.52	4.7	9.03	9.4
5	0.23	0.24	0.9	0.94	1.81	1.88	3.61	3.76	5.42	5.64	10.84	11.28
6	0.26	0.27	1.05	1.1	2.11	2.19	4.21	4.39	6.32	6.58	12.64	13.16
7	0.3	0.31	1.2	1.25	2.41	2.51	4.82	5.01	7.23	7.52	14.45	15.04
8	0.34	0.35	1.35	1.41	2.71	2.82	5.42	5.64	8.13	8.46	16.26	16.92
9	0.38	0.39	1.51	1.57	3.01	3.13	6.02	6.27	9.03	9.4	18.06	18.8
10	0.41	0.43	1.66	1.72	3.31	3.45	6.62	6.89	9.93	10.34	19.87	20.68
11	0.45	0.47	1.81	1.88	3.61	3.76	7.23	7.52	10.84	11.28	21.68	22.56
12	0.49	0.51	1.96	2.04	3.91	4.07	7.83	8.15	11.74	12.22	23.48	24.44
13	0.53	0.55	2.11	2.19	4.21	4.39	8.43	8.77	12.64	13.16	25.29	26.32
14	0.56	0.59	2.26	2.35	4.52	4.7	9.03	9.4	13.55	14.1	27.1	28.2
15	0.6	0.63	2.41	2.51	4.82	5.01	9.63	10.03	14.45	15.04	28.9	30.08
16	0.64	0.67	2.56	2.66	5.12	5.33	10.24	10.65	15.35	15.98	30.71	31.96
17	0.68	0.71	2.71	2.82	5.42	5.64	10.84	11.28	16.26	16.92	32.51	33.84
18	0.72	0.74	2.86	2.98	5.72	5.95	11.44	11.91	17.16	17.86	34.32	35.72
19	0.75	0.78	3.01	3.13	6.02	6.27	12.04	12.53	18.06	18.8	36.13	37.6
20	0.79	0.82	3.16	3.29	6.32	6.58	12.64	13.16	18.97	19.74	37.93	39.48
21	0.83	0.86	3.31	3.45	6.62	6.89	13.25	13.79	19.87	20.68	39.74	NA
22	0.87	0.9	3.46	3.6	6.92	7.21	13.85	14.41	20.77	21.62	NA	NA
23	0.9	0.94	3.61	3.76	7.23	7.52	14.45	15.04	21.68	22.56	NA	NA
24	0.94	0.98	3.76	3.92	7.53	7.83	15.05	15.67	22.58	23.5	NA	NA
25	0.98	1.02	3.91	4.07	7.83	8.15	15.65	16.29	23.48	24.44	NA	NA
26	1.02	1.06	4.06	4.23	8.13	8.46	16.26	16.92	24.39	25.38	NA	NA
27	1.05	1.1	4.21	4.39	8.43	8.77	16.86	17.55	25.29	26.32	NA	NA
28	1.09	1.14	4.37	4.54	8.73	9.09	17.46	18.17	26.19	27.26	NA	NA
29	1.13	1.18	4.52	4.7	9.03	9.4	18.06	18.8	27.1	28.2	NA	NA
30	1.17	1.21	4.67	4.86	9.33	9.71	18.67	19.43	28	29.14	NA	NA
31	1.2	1.25	4.82	5.01	9.63	10.03	19.27	20.05	28.9	30.08	NA	NA
32	1.24	1.29	4.97	5.17	9.93	10.34	19.87	20.68	29.8	31.02	NA	NA
33	1.28	1.33	5.12	5.33	10.24	10.65	20.47	21.31	30.71	31.96	NA	NA
34	1.32	1.37	5.27	5.48	10.54	10.97	21.07	21.93	31.61	32.9	NA	NA
35	1.35	1.41	5.42	5.64	10.84	11.28	21.68	22.56	32.51	33.84	NA	NA
36	1.39	1.45	5.57	5.8	11.14	11.59	22.28	23.19	33.42	34.78	NA	NA
37	1.43	1.49	5.72	5.95	11.44	11.91	22.88	23.81	34.32	35.72	NA	NA
38	1.47	1.53	5.87	6.11	11.74	12.22	23.48	24.44	35.22	36.66	NA	NA
39	1.51	1.57	6.02	6.27	12.04	12.53	24.08	25.07	36.13	37.6	NA	NA
40	1.54	1.61	6.17	6.42	12.34	12.85	24.69	25.69	37.03	38.54	NA	NA
41	1.58	1.65	6.32	6.58	12.64	13.16	25.29	26.32	37.93	39.48	NA	NA
42	1.62	1.68	6.47	6.74	12.95	13.47	25.89	26.95	38.84	NA	NA	NA
43	1.66	1.72	6.62	6.89	13.25	13.79	26.49	27.57	39.74	NA	NA	NA
44	1.69	1.76	6.77	7.05	13.55	14.1	27.1	28.2	NA	NA	NA	NA
45	1.73	1.8	6.92	7.21	13.85	14.41	27.7	28.83	NA	NA	NA	NA
46	1.77	1.84	7.07	7.36	14.15	14.73	28.3	29.45	NA	NA	NA	NA
47	1.81	1.88	7.23	7.52	14.45	15.04	28.9	30.08	NA	NA	NA	NA
48	1.84	1.92	7.38	7.68	14.75	15.35	29.5	30.71	NA	NA	NA	NA
49	1.88	1.96	7.53	7.83	15.05	15.67	30.11	31.33	NA	NA	NA	NA
50	1.92	2	7.68	7.99	15.35	15.98	30.71	31.96	NA	NA	NA	NA

Note: Shaded cells indicate discontinuous region of operation, which could lead to a degenerate condition. Verify your oscillator selection to be certain you can synchronize to the device at the selected baud rate.

TABLE B-1: Fosc (MHz) FOR VARIOUS BAUD RATES (F(X,B), FOR $\pm 2\%$ ERROR) (CONTINUED)

SPBRG (X)	Baud Rate (B)											
	2400		9600		19200		38400		57600		115200	
	Low	High	Low	High	Low	High	Low	High	Low	High	Low	High
51	1.96	2.04	7.83	8.15	15.65	16.29	31.31	32.59	NA	NA	NA	NA
52	1.99	2.08	7.98	8.3	15.96	16.61	31.91	33.21	NA	NA	NA	NA
53	2.03	2.12	8.13	8.46	16.26	16.92	32.51	33.84	NA	NA	NA	NA
54	2.07	2.15	8.28	8.62	16.56	17.23	33.12	34.47	NA	NA	NA	NA
55	2.11	2.19	8.43	8.77	16.86	17.55	33.72	35.09	NA	NA	NA	NA
56	2.15	2.23	8.58	8.93	17.16	17.86	34.32	35.72	NA	NA	NA	NA
57	2.18	2.27	8.73	9.09	17.46	18.17	34.92	36.35	NA	NA	NA	NA
58	2.22	2.31	8.88	9.24	17.76	18.49	35.52	36.97	NA	NA	NA	NA
59	2.26	2.35	9.03	9.4	18.06	18.8	36.13	37.6	NA	NA	NA	NA
60	2.3	2.39	9.18	9.56	18.36	19.11	36.73	38.23	NA	NA	NA	NA
61	2.33	2.43	9.33	9.71	18.67	19.43	37.33	38.85	NA	NA	NA	NA
62	2.37	2.47	9.48	9.87	18.97	19.74	37.93	39.48	NA	NA	NA	NA
63	2.41	2.51	9.63	10.03	19.27	20.05	38.54	NA	NA	NA	NA	NA
64	2.45	2.55	9.78	10.18	19.57	20.37	39.14	NA	NA	NA	NA	NA
65	2.48	2.59	9.93	10.34	19.87	20.68	39.74	NA	NA	NA	NA	NA
66	2.52	2.62	10.09	10.5	20.17	20.99	NA	NA	NA	NA	NA	NA
67	2.56	2.66	10.24	10.65	20.47	21.31	NA	NA	NA	NA	NA	NA
68	2.6	2.7	10.39	10.81	20.77	21.62	NA	NA	NA	NA	NA	NA
69	2.63	2.74	10.54	10.97	21.07	21.93	NA	NA	NA	NA	NA	NA
70	2.67	2.78	10.69	11.12	21.37	22.25	NA	NA	NA	NA	NA	NA
71	2.71	2.82	10.84	11.28	21.68	22.56	NA	NA	NA	NA	NA	NA
72	2.75	2.86	10.99	11.44	21.98	22.87	NA	NA	NA	NA	NA	NA
73	2.78	2.9	11.14	11.59	22.28	23.19	NA	NA	NA	NA	NA	NA
74	2.82	2.94	11.29	11.75	22.58	23.5	NA	NA	NA	NA	NA	NA
75	2.86	2.98	11.44	11.91	22.88	23.81	NA	NA	NA	NA	NA	NA
76	2.9	3.02	11.59	12.06	23.18	24.13	NA	NA	NA	NA	NA	NA
77	2.94	3.06	11.74	12.22	23.48	24.44	NA	NA	NA	NA	NA	NA
78	2.97	3.09	11.89	12.38	23.78	24.75	NA	NA	NA	NA	NA	NA
79	3.01	3.13	12.04	12.53	24.08	25.07	NA	NA	NA	NA	NA	NA
80	3.05	3.17	12.19	12.69	24.39	25.38	NA	NA	NA	NA	NA	NA
81	3.09	3.21	12.34	12.85	24.69	25.69	NA	NA	NA	NA	NA	NA
82	3.12	3.25	12.49	13	24.99	26.01	NA	NA	NA	NA	NA	NA
83	3.16	3.29	12.64	13.16	25.29	26.32	NA	NA	NA	NA	NA	NA
84	3.2	3.33	12.79	13.32	25.59	26.63	NA	NA	NA	NA	NA	NA
85	3.24	3.37	12.95	13.47	25.89	26.95	NA	NA	NA	NA	NA	NA
86	3.27	3.41	13.1	13.63	26.19	27.26	NA	NA	NA	NA	NA	NA
87	3.31	3.45	13.25	13.79	26.49	27.57	NA	NA	NA	NA	NA	NA
88	3.35	3.49	13.4	13.94	26.79	27.89	NA	NA	NA	NA	NA	NA
89	3.39	3.53	13.55	14.1	27.1	28.2	NA	NA	NA	NA	NA	NA
90	3.42	3.56	13.7	14.26	27.4	28.51	NA	NA	NA	NA	NA	NA
91	3.46	3.6	13.85	14.41	27.7	28.83	NA	NA	NA	NA	NA	NA
92	3.5	3.64	14	14.57	28	29.14	NA	NA	NA	NA	NA	NA
93	3.54	3.68	14.15	14.73	28.3	29.45	NA	NA	NA	NA	NA	NA
94	3.58	3.72	14.3	14.88	28.6	29.77	NA	NA	NA	NA	NA	NA
95	3.61	3.76	14.45	15.04	28.9	30.08	NA	NA	NA	NA	NA	NA
96	3.65	3.8	14.6	15.2	29.2	30.39	NA	NA	NA	NA	NA	NA
97	3.69	3.84	14.75	15.35	29.5	30.71	NA	NA	NA	NA	NA	NA
98	3.73	3.88	14.9	15.51	29.8	31.02	NA	NA	NA	NA	NA	NA
99	3.76	3.92	15.05	15.67	30.11	31.33	NA	NA	NA	NA	NA	NA
100	3.8	3.96	15.2	15.82	30.41	31.65	NA	NA	NA	NA	NA	NA
101	3.84	4	15.35	15.98	30.71	31.96	NA	NA	NA	NA	NA	NA
102	3.88	4.03	15.5	16.14	31.01	32.27	NA	NA	NA	NA	NA	NA

Note: Shaded cells indicate discontinuous region of operation, which could lead to a degenerate condition. Verify your oscillator selection to be certain you can synchronize to the device at the selected baud rate.

AN851

TABLE B-1: Fosc (MHZ) FOR VARIOUS BAUD RATES (F(X,B), FOR ±2% ERROR) (CONTINUED)

SPBRG (X)	Baud Rate (B)											
	2400		9600		19200		38400		57600		115200	
	Low	High	Low	High	Low	High	Low	High	Low	High	Low	High
103	3.91	4.07	15.65	16.29	31.31	32.59	NA	NA	NA	NA	NA	NA
104	3.95	4.11	15.81	16.45	31.61	32.9	NA	NA	NA	NA	NA	NA
105	3.99	4.15	15.96	16.61	31.91	33.21	NA	NA	NA	NA	NA	NA
106	4.03	4.19	16.11	16.76	32.21	33.53	NA	NA	NA	NA	NA	NA
107	4.06	4.23	16.26	16.92	32.51	33.84	NA	NA	NA	NA	NA	NA
108	4.1	4.27	16.41	17.08	32.82	34.15	NA	NA	NA	NA	NA	NA
109	4.14	4.31	16.56	17.23	33.12	34.47	NA	NA	NA	NA	NA	NA
110	4.18	4.35	16.71	17.39	33.42	34.78	NA	NA	NA	NA	NA	NA
111	4.21	4.39	16.86	17.55	33.72	35.09	NA	NA	NA	NA	NA	NA
112	4.25	4.43	17.01	17.7	34.02	35.41	NA	NA	NA	NA	NA	NA
113	4.29	4.47	17.16	17.86	34.32	35.72	NA	NA	NA	NA	NA	NA
114	4.33	4.5	17.31	18.02	34.62	36.03	NA	NA	NA	NA	NA	NA
115	4.37	4.54	17.46	18.17	34.92	36.35	NA	NA	NA	NA	NA	NA
116	4.4	4.58	17.61	18.33	35.22	36.66	NA	NA	NA	NA	NA	NA
117	4.44	4.62	17.76	18.49	35.52	36.97	NA	NA	NA	NA	NA	NA
118	4.48	4.66	17.91	18.64	35.83	37.29	NA	NA	NA	NA	NA	NA
119	4.52	4.7	18.06	18.8	36.13	37.6	NA	NA	NA	NA	NA	NA
120	4.55	4.74	18.21	18.96	36.43	37.91	NA	NA	NA	NA	NA	NA
121	4.59	4.78	18.36	19.11	36.73	38.23	NA	NA	NA	NA	NA	NA
122	4.63	4.82	18.51	19.27	37.03	38.54	NA	NA	NA	NA	NA	NA
123	4.67	4.86	18.67	19.43	37.33	38.85	NA	NA	NA	NA	NA	NA
124	4.7	4.9	18.82	19.58	37.63	39.17	NA	NA	NA	NA	NA	NA
125	4.74	4.94	18.97	19.74	37.93	39.48	NA	NA	NA	NA	NA	NA
126	4.78	4.97	19.12	19.9	38.23	39.79	NA	NA	NA	NA	NA	NA
127	4.82	5.01	19.27	20.05	38.54	NA	NA	NA	NA	NA	NA	NA
128	4.85	5.05	19.42	20.21	38.84	NA	NA	NA	NA	NA	NA	NA
129	4.89	5.09	19.57	20.37	39.14	NA	NA	NA	NA	NA	NA	NA
130	4.93	5.13	19.72	20.52	39.44	NA	NA	NA	NA	NA	NA	NA
131	4.97	5.17	19.87	20.68	39.74	NA	NA	NA	NA	NA	NA	NA
132	5.01	5.21	20.02	20.84	NA	NA	NA	NA	NA	NA	NA	NA
133	5.04	5.25	20.17	20.99	NA	NA	NA	NA	NA	NA	NA	NA
134	5.08	5.29	20.32	21.15	NA	NA	NA	NA	NA	NA	NA	NA
135	5.12	5.33	20.47	21.31	NA	NA	NA	NA	NA	NA	NA	NA
136	5.16	5.37	20.62	21.46	NA	NA	NA	NA	NA	NA	NA	NA
137	5.19	5.41	20.77	21.62	NA	NA	NA	NA	NA	NA	NA	NA
138	5.23	5.44	20.92	21.78	NA	NA	NA	NA	NA	NA	NA	NA
139	5.27	5.48	21.07	21.93	NA	NA	NA	NA	NA	NA	NA	NA
140	5.31	5.52	21.22	22.09	NA	NA	NA	NA	NA	NA	NA	NA
141	5.34	5.56	21.37	22.25	NA	NA	NA	NA	NA	NA	NA	NA
142	5.38	5.6	21.53	22.4	NA	NA	NA	NA	NA	NA	NA	NA
143	5.42	5.64	21.68	22.56	NA	NA	NA	NA	NA	NA	NA	NA
144	5.46	5.68	21.83	22.72	NA	NA	NA	NA	NA	NA	NA	NA
145	5.49	5.72	21.98	22.87	NA	NA	NA	NA	NA	NA	NA	NA
146	5.53	5.76	22.13	23.03	NA	NA	NA	NA	NA	NA	NA	NA
147	5.57	5.8	22.28	23.19	NA	NA	NA	NA	NA	NA	NA	NA
148	5.61	5.84	22.43	23.34	NA	NA	NA	NA	NA	NA	NA	NA
149	5.64	5.88	22.58	23.5	NA	NA	NA	NA	NA	NA	NA	NA
150	5.68	5.91	22.73	23.66	NA	NA	NA	NA	NA	NA	NA	NA
151	5.72	5.95	22.88	23.81	NA	NA	NA	NA	NA	NA	NA	NA
152	5.76	5.99	23.03	23.97	NA	NA	NA	NA	NA	NA	NA	NA
153	5.8	6.03	23.18	24.13	NA	NA	NA	NA	NA	NA	NA	NA
154	5.83	6.07	23.33	24.28	NA	NA	NA	NA	NA	NA	NA	NA

Note: Shaded cells indicate discontinuous region of operation, which could lead to a degenerate condition. Verify your oscillator selection to be certain you can synchronize to the device at the selected baud rate.

TABLE B-1: Fosc (MHz) FOR VARIOUS BAUD RATES (F(X,B), FOR $\pm 2\%$ ERROR) (CONTINUED)

SPBRG (X)	Baud Rate (B)											
	2400		9600		19200		38400		57600		115200	
	Low	High	Low	High	Low	High	Low	High	Low	High	Low	High
155	5.87	6.11	23.48	24.44	NA	NA	NA	NA	NA	NA	NA	NA
156	5.91	6.15	23.63	24.6	NA	NA	NA	NA	NA	NA	NA	NA
157	5.95	6.19	23.78	24.75	NA	NA	NA	NA	NA	NA	NA	NA
158	5.98	6.23	23.93	24.91	NA	NA	NA	NA	NA	NA	NA	NA
159	6.02	6.27	24.08	25.07	NA	NA	NA	NA	NA	NA	NA	NA
160	6.06	6.31	24.24	25.22	NA	NA	NA	NA	NA	NA	NA	NA
161	6.1	6.35	24.39	25.38	NA	NA	NA	NA	NA	NA	NA	NA
162	6.13	6.38	24.54	25.54	NA	NA	NA	NA	NA	NA	NA	NA
163	6.17	6.42	24.69	25.69	NA	NA	NA	NA	NA	NA	NA	NA
164	6.21	6.46	24.84	25.85	NA	NA	NA	NA	NA	NA	NA	NA
165	6.25	6.5	24.99	26.01	NA	NA	NA	NA	NA	NA	NA	NA
166	6.28	6.54	25.14	26.16	NA	NA	NA	NA	NA	NA	NA	NA
167	6.32	6.58	25.29	26.32	NA	NA	NA	NA	NA	NA	NA	NA
168	6.36	6.62	25.44	26.48	NA	NA	NA	NA	NA	NA	NA	NA
169	6.4	6.66	25.59	26.63	NA	NA	NA	NA	NA	NA	NA	NA
170	6.44	6.7	25.74	26.79	NA	NA	NA	NA	NA	NA	NA	NA
171	6.47	6.74	25.89	26.95	NA	NA	NA	NA	NA	NA	NA	NA
172	6.51	6.78	26.04	27.1	NA	NA	NA	NA	NA	NA	NA	NA
173	6.55	6.82	26.19	27.26	NA	NA	NA	NA	NA	NA	NA	NA
174	6.59	6.85	26.34	27.42	NA	NA	NA	NA	NA	NA	NA	NA
175	6.62	6.89	26.49	27.57	NA	NA	NA	NA	NA	NA	NA	NA
176	6.66	6.93	26.64	27.73	NA	NA	NA	NA	NA	NA	NA	NA
177	6.7	6.97	26.79	27.89	NA	NA	NA	NA	NA	NA	NA	NA
178	6.74	7.01	26.94	28.04	NA	NA	NA	NA	NA	NA	NA	NA
179	6.77	7.05	27.1	28.2	NA	NA	NA	NA	NA	NA	NA	NA
180	6.81	7.09	27.25	28.36	NA	NA	NA	NA	NA	NA	NA	NA
181	6.85	7.13	27.4	28.51	NA	NA	NA	NA	NA	NA	NA	NA
182	6.89	7.17	27.55	28.67	NA	NA	NA	NA	NA	NA	NA	NA
183	6.92	7.21	27.7	28.83	NA	NA	NA	NA	NA	NA	NA	NA
184	6.96	7.25	27.85	28.98	NA	NA	NA	NA	NA	NA	NA	NA
185	7	7.29	28	29.14	NA	NA	NA	NA	NA	NA	NA	NA
186	7.04	7.32	28.15	29.3	NA	NA	NA	NA	NA	NA	NA	NA
187	7.07	7.36	28.3	29.45	NA	NA	NA	NA	NA	NA	NA	NA
188	7.11	7.4	28.45	29.61	NA	NA	NA	NA	NA	NA	NA	NA
189	7.15	7.44	28.6	29.77	NA	NA	NA	NA	NA	NA	NA	NA
190	7.19	7.48	28.75	29.92	NA	NA	NA	NA	NA	NA	NA	NA
191	7.23	7.52	28.9	30.08	NA	NA	NA	NA	NA	NA	NA	NA
192	7.26	7.56	29.05	30.24	NA	NA	NA	NA	NA	NA	NA	NA
193	7.3	7.6	29.2	30.39	NA	NA	NA	NA	NA	NA	NA	NA
194	7.34	7.64	29.35	30.55	NA	NA	NA	NA	NA	NA	NA	NA
195	7.38	7.68	29.5	30.71	NA	NA	NA	NA	NA	NA	NA	NA
196	7.41	7.72	29.65	30.86	NA	NA	NA	NA	NA	NA	NA	NA
197	7.45	7.76	29.8	31.02	NA	NA	NA	NA	NA	NA	NA	NA
198	7.49	7.79	29.96	31.18	NA	NA	NA	NA	NA	NA	NA	NA
199	7.53	7.83	30.11	31.33	NA	NA	NA	NA	NA	NA	NA	NA
200	7.56	7.87	30.26	31.49	NA	NA	NA	NA	NA	NA	NA	NA
201	7.6	7.91	30.41	31.65	NA	NA	NA	NA	NA	NA	NA	NA
202	7.64	7.95	30.56	31.8	NA	NA	NA	NA	NA	NA	NA	NA
203	7.68	7.99	30.71	31.96	NA	NA	NA	NA	NA	NA	NA	NA
204	7.71	8.03	30.86	32.12	NA	NA	NA	NA	NA	NA	NA	NA
205	7.75	8.07	31.01	32.27	NA	NA	NA	NA	NA	NA	NA	NA
206	7.79	8.11	31.16	32.43	NA	NA	NA	NA	NA	NA	NA	NA

Note: Shaded cells indicate discontinuous region of operation, which could lead to a degenerate condition. Verify your oscillator selection to be certain you can synchronize to the device at the selected baud rate.

AN851

TABLE B-1: Fosc (MHZ) FOR VARIOUS BAUD RATES (F(X,B), FOR ±2% ERROR) (CONTINUED)

SPBRG (X)	Baud Rate (B)											
	2400		9600		19200		38400		57600		115200	
	Low	High	Low	High	Low	High	Low	High	Low	High	Low	High
207	7.83	8.15	31.31	32.59	NA	NA	NA	NA	NA	NA	NA	NA
208	7.87	8.19	31.46	32.74	NA	NA	NA	NA	NA	NA	NA	NA
209	7.9	8.23	31.61	32.9	NA	NA	NA	NA	NA	NA	NA	NA
210	7.94	8.26	31.76	33.06	NA	NA	NA	NA	NA	NA	NA	NA
211	7.98	8.3	31.91	33.21	NA	NA	NA	NA	NA	NA	NA	NA
212	8.02	8.34	32.06	33.37	NA	NA	NA	NA	NA	NA	NA	NA
213	8.05	8.38	32.21	33.53	NA	NA	NA	NA	NA	NA	NA	NA
214	8.09	8.42	32.36	33.68	NA	NA	NA	NA	NA	NA	NA	NA
215	8.13	8.46	32.51	33.84	NA	NA	NA	NA	NA	NA	NA	NA
216	8.17	8.5	32.66	34	NA	NA	NA	NA	NA	NA	NA	NA
217	8.2	8.54	32.82	34.15	NA	NA	NA	NA	NA	NA	NA	NA
218	8.24	8.58	32.97	34.31	NA	NA	NA	NA	NA	NA	NA	NA
219	8.28	8.62	33.12	34.47	NA	NA	NA	NA	NA	NA	NA	NA
220	8.32	8.66	33.27	34.62	NA	NA	NA	NA	NA	NA	NA	NA
221	8.35	8.7	33.42	34.78	NA	NA	NA	NA	NA	NA	NA	NA
222	8.39	8.73	33.57	34.94	NA	NA	NA	NA	NA	NA	NA	NA
223	8.43	8.77	33.72	35.09	NA	NA	NA	NA	NA	NA	NA	NA
224	8.47	8.81	33.87	35.25	NA	NA	NA	NA	NA	NA	NA	NA
225	8.5	8.85	34.02	35.41	NA	NA	NA	NA	NA	NA	NA	NA
226	8.54	8.89	34.17	35.56	NA	NA	NA	NA	NA	NA	NA	NA
227	8.58	8.93	34.32	35.72	NA	NA	NA	NA	NA	NA	NA	NA
228	8.62	8.97	34.47	35.88	NA	NA	NA	NA	NA	NA	NA	NA
229	8.66	9.01	34.62	36.03	NA	NA	NA	NA	NA	NA	NA	NA
230	8.69	9.05	34.77	36.19	NA	NA	NA	NA	NA	NA	NA	NA
231	8.73	9.09	34.92	36.35	NA	NA	NA	NA	NA	NA	NA	NA
232	8.77	9.13	35.07	36.5	NA	NA	NA	NA	NA	NA	NA	NA
233	8.81	9.17	35.22	36.66	NA	NA	NA	NA	NA	NA	NA	NA
234	8.84	9.2	35.37	36.82	NA	NA	NA	NA	NA	NA	NA	NA
235	8.88	9.24	35.52	36.97	NA	NA	NA	NA	NA	NA	NA	NA
236	8.92	9.28	35.68	37.13	NA	NA	NA	NA	NA	NA	NA	NA
237	8.96	9.32	35.83	37.29	NA	NA	NA	NA	NA	NA	NA	NA
238	8.99	9.36	35.98	37.44	NA	NA	NA	NA	NA	NA	NA	NA
239	9.03	9.4	36.13	37.6	NA	NA	NA	NA	NA	NA	NA	NA
240	9.07	9.44	36.28	37.76	NA	NA	NA	NA	NA	NA	NA	NA
241	9.11	9.48	36.43	37.91	NA	NA	NA	NA	NA	NA	NA	NA
242	9.14	9.52	36.58	38.07	NA	NA	NA	NA	NA	NA	NA	NA
243	9.18	9.56	36.73	38.23	NA	NA	NA	NA	NA	NA	NA	NA
244	9.22	9.6	36.88	38.38	NA	NA	NA	NA	NA	NA	NA	NA
245	9.26	9.64	37.03	38.54	NA	NA	NA	NA	NA	NA	NA	NA
246	9.3	9.67	37.18	38.7	NA	NA	NA	NA	NA	NA	NA	NA
247	9.33	9.71	37.33	38.85	NA	NA	NA	NA	NA	NA	NA	NA
248	9.37	9.75	37.48	39.01	NA	NA	NA	NA	NA	NA	NA	NA
249	9.41	9.79	37.63	39.17	NA	NA	NA	NA	NA	NA	NA	NA
250	9.45	9.83	37.78	39.32	NA	NA	NA	NA	NA	NA	NA	NA
251	9.48	9.87	37.93	39.48	NA	NA	NA	NA	NA	NA	NA	NA
252	9.52	9.91	38.08	39.64	NA	NA	NA	NA	NA	NA	NA	NA
253	9.56	9.95	38.23	39.79	NA	NA	NA	NA	NA	NA	NA	NA
254	9.6	9.99	38.38	39.95	NA	NA	NA	NA	NA	NA	NA	NA
255	9.63	10.03	38.54	NA	NA	NA	NA	NA	NA	NA	NA	NA

Note: Shaded cells indicate discontinuous region of operation, which could lead to a degenerate condition. Verify your oscillator selection to be certain you can synchronize to the device at the selected baud rate.

Software License Agreement

The software supplied herewith by Microchip Technology Incorporated (the "Company") is intended and supplied to you, the Company's customer, for use solely and exclusively on Microchip products.

The software is owned by the Company and/or its supplier, and is protected under applicable copyright laws. All rights are reserved. Any use in violation of the foregoing restrictions may subject the user to criminal sanctions under applicable laws, as well as to civil liability for the breach of the terms and conditions of this license.

THIS SOFTWARE IS PROVIDED IN AN "AS IS" CONDITION. NO WARRANTIES, WHETHER EXPRESS, IMPLIED OR STATUTORY, INCLUDING, BUT NOT LIMITED TO, IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE APPLY TO THIS SOFTWARE. THE COMPANY SHALL NOT, IN ANY CIRCUMSTANCES, BE LIABLE FOR SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES, FOR ANY REASON WHATSOEVER.

APPENDIX C: BOOTLOADER FIRMWARE

C.1 PIC18F Bootloader Firmware

```
; *****
;
; Bootloader for PIC18F by Ross Fosler
; 03/01/2002 ... First full implementation
; 03/07/2002 Changed entry method to use last byte of EEDATA.
; Also removed all possible infinite loops w/ clrwdt.
; 03/07/2002 Added code for direct boot entry. I.E. boot vector.
; 03/09/2002 Changed the general packet format, removed the LEN field.
; 03/09/2002 Modified the erase command to do multiple row erase.
; 03/12/2002 Fixed write problem to CONFIG area. Write was offset by a byte.
; 03/15/2002 Added work around for 18F8720 tblwt*+ problem.
; 03/20/2002 Modified receive & parse engine to vector to autobaud on a checksum
; error since a checksum error could likely be a communications problem.
; 03/22/2002 Removed clrwdt from the startup. This instruction affects the TO and
; PD flags. Removing this instruction should have no affect on code
; operation since the WDT is cleared on a reset and boot entry is always
; on a reset.
; 03/22/2002 Modified the protocol to incorporate the autobaud as part of the
; first received <STX>. Doing this improves robustness by allowing
; re-sync under any condition. Previously it was possible to enter a
; state where only a hard reset would allow re-syncing.
;
; Memory Map
;
; -----
; | 0x0000 |
; | 0x0002 | Boot vector
; | 0x0004 | Unlock & write vector
; |
; | Boot Block | (this program)
; |
; | 0x0200 | Re-mapped Reset Vector
; | 0x0208 | Re-mapped High Priority Interrupt Vector
; | 0x0218 | Re-mapped Low Priority Interrupt Vector
; | |
; |
; | Code Space | User program space
; | |
; | |
; | 0xXXXXXX |
; |-----|
;
;
;
```

AN851

```
; Incoming data format:
;
;   <STX><STX><DATA><CHKSUM><ETX>
;
;   /      \
;  _____\
; /
; <COMMAND><DLEN><ADDRL><ADDRH><ADDRU><DATA>...
;
; Definitions:
;
; STX   - Start of packet indicator
; ETX   - End of packet indicator
; LEN   - Length of incoming packet
; DATA - General data up to 255 bytes
; CHKSUM - The 8-bit two's compliment sum of LEN & DATA
; COMMAND - Base command
; DLEN  - Length of data associated to the command
; ADDR  - Address up to 24 bits
; DATA - Data (if any)
;
;
; Commands:
;
; RD_VER    0x00    Read Version Information
; RD_MEM    0x01    Read Program Memory
; WR_MEM    0x02    Write Program Memory
; ER_MEM    0x03    Erase Program Memory
; RD_EE     0x04    Read EEDATA Memory
; WR_EE     0x05    Write EEDATA Memory
; RD_CONFIG 0x06    Read Config Memory
; WT_CONFIG 0x07    Write Config Memory
;
; *****

; *****
; #include P18F452.INC          ; Standard include
; #include P18F8720.inc
; *****

; *****
#define MINOR_VERSION 0x09      ; Version
#define MAJOR_VERSION 0x00

#define RC_DLE        0x01
#define RC_STX        0x02

#define STX           0x0F
#define ETX           0x04
#define DLE           0x05

#define TBLWT_BUG     ; Timing bug found in some PIC18Fxx20s
; *****

; *****
CHKSUM    equ 0x00          ; Checksum accumulator
COUNTER   equ 0x01          ; General counter
ABTIME_H  equ 0x02
ABTIME_L  equ 0x03
RXDATA    equ 0x04
```



```

TXDATA      equ 0x05

; Frame Format
;
; <STX><STX>[<COMMAND><DATALEN><ADDRL><ADDRH><ADDRU><...DATA...>]<CHKSUM><ETX>

DATA_BUFF   equ 0x08                ; Start of receive buffer

COMMAND     equ 0x08                ; Data mapped in receive buffer
DATA_COUNT  equ 0x09
ADDRESS_L   equ 0x0A
ADDRESS_H   equ 0x0B
ADDRESS_U   equ 0x0C
PACKET_DATA equ 0x0D
; *****

; *****
pmwtpi macro                                ; tblwt*+ macro for PIC18Fxx20 bug
IFDEF TBLWT_BUG
    tblwt*+
    tblrd*+
ELSE
    tblwt*+
ENDIF
endm
; *****

; *****
ORG      0x0000                ; Re-map Reset vector
bra      Setup
bra      BootMode
bra      StartWrite
bra      WriteWaitEEData


ORG      0x0008
VIntH
bra      RVIntH                ; Re-map Interrupt vector

ORG      0x0018
VIntL
bra      RVIntL                ; Re-map Interrupt vector
; *****

; *****
; Setup the appropriate registers.
Setup
    clrf   EECON1
    setf   EEADR                ; Point to last location
    setf   EEADRH
    bsf    EECON1, RD           ; Read the control code
    incfsz EECON1, W
    bra    RVReset             ; If not 0xFF then normal reset
    bcf    TRISC, 6            ; Setup tx pin
;    bsf    TRISC, 7            ; Setup rx pin
    movlw b'10010000'          ; Setup rx and tx
    movwf  CSTA1
    movlw  b'00100110'
    movwf  TXSTA1
; *****

```

AN851

```
; *****
Autobaud
;
;
; 
;
; p = The number of instructions between the first and last
; rising edge of the RS232 control sequence 0x0F.
; Other possible control sequences are 0x01, 0x03, 0x07, 0x1F,
; 0x3F, 0x7F.
;
; SPBRG = (p / 32) - 1, BRGH = 1

bcf    RCSTA1, CREN          ; Stop receiving
movlw  b'00000011'          ; x16 Prescale
movwf  TOCON
clrf   TMR0H                 ; Reset timer
clrf   TMR0L
rcall  WaitForRise
bsf    TOCON, TMR0ON         ; Start counting
rcall  WaitForRise
bcf    TOCON, TMR0ON         ; Stop counting
movff  TMR0L, ABTIME_L      ; Read the timer

DivB32
rrcf   TMR0H, F              ; divide by 2
rrcf   ABTIME_L, F
btfss  STATUS, C            ; Rounding
decf   ABTIME_L, F
movff  ABTIME_L, SPBRG1     ; Sync
bsf    RCSTA1, CREN         ; Start receiving
movf   RCREG1, W            ; Empty the buffer
movf   RCREG1, W
; *****

; *****
; Read and parse the data.
StartOfLine
rcall  RdRS232              ; Get second <STX>
xorlw  STX
bnz    Autobaud             ; Otherwise go back for another character
lfsr   0, DATA_BUFF        ; Point to the buffer
clrf   CHKSUM               ; Reset checksum
clrf   COUNTER              ; Reset buffer count

GetNextDat
rcall  RdRS232              ; Get the data
xorlw  STX                  ; Check for a STX
bz     StartOfLine          ; Yes, start over

NoSTX
movf   RXDATA, W
xorlw  ETX                  ; Check for a ETX
bz     CheckSum             ; Yes, examine checksum

NoETX
movf   RXDATA, W
xorlw  DLE                  ; Check for a DLE
bnz    NoDLE
rcall  RdRS232              ; Yes, Get the next byte

NoDLE
movf   RXDATA, W
addwf  CHKSUM, F            ; Get sum
movwf  POSTINC0             ; Store the data
dcfsnz COUNTER, F          ; Limit buffer to 256 bytes
```

```

    bra    Autobaud
    bra    GetNextDat
Checksum
    movf   CHKSUM                ; Checksum test
    bnz    Autobaud
; *****

; *****
; Pre-setup, common to all commands.
    movf   ADDRESS_L, W          ; Set all possible pointers
    movwf  TBLPTRL
    movwf  EEADR
    movf   ADDRESS_H, W
    movwf  TBLPTRH
    movwf  EEADRH
    movff  ADDRESS_U, TBLPTRU
    lfsr   FSR0, PACKET_DATA
    movf   DATA_COUNT, W       ; Setup counter
    movwf  COUNTER
    btfsc  STATUS, Z
    reset                                ; Non valid count (Special Command)
; *****

; *****
; Test the command field and sub-command.
Checksum
    movf   COMMAND, W           ; Test for a valid command
    sublw  d'7'
    bnc    Autobaud
    clrf   PCLATH                ; Setup for a calculated jump
    clrf   PCLATU
    rlncf  COMMAND, W           ; Jump
    addwf  PCL, F
    bra    ReadVersion
    bra    ReadProgMem
    bra    WriteProgMem
    bra    EraseProgMem
    bra    ReadEE
    bra    WriteEE
    bra    ReadProgMem          ;ReadConfig
    bra    WriteConfig
; *****

; *****
; Commands
;
; In:   <STX><STX>[<0x00><0x02>]<0xFF><ETX>
; OUT:  <STX><STX>[<0x00><0x02><VERL><VERH>]<CHKSUM><ETX>

ReadVersion
    movlw  MINOR_VERSION
    movwf  DATA_BUFF + 2
    movlw  MAJOR_VERSION
    movwf  DATA_BUFF + 3
    movlw  0x04
    bra    WritePacket

; In:   <STX><STX>[<0x01><DLEN><ADDRL><ADDRH><ADDRU>]<CHKSUM><ETX>
; OUT:  <STX><STX>[<0x01><DLEN><ADDRL><ADDRH><ADDRU><DATA>...]<CHKSUM><ETX>

```

AN851

```
ReadProgMem
    tblrd    *+                ; Fill buffer
    movff   TABLAT, POSTINC0
    decfsz  COUNTER, F
    bra     ReadProgMem       ; Not finished then repeat
    movf    DATA_COUNT, W    ; Setup packet length
    addlw   0x05
    bra     WritePacket

; In:  <STX><STX>[<0x02><DLENBLOCK><ADDRL><ADDRH><ADDRU><DATA>...]<CHKSUM><ETX>
; OUT: <STX><STX>[<0x02>]<CHKSUM><ETX>

WriteProgMem
    movlw   b'11111000'       ; Force a boundry
    andwf   TBLPTRL, F
    movlw   0x08
Lp1
    movff   POSTINC0, TABLAT   ; Load the holding registers
    pmwtpi                ; Same as tblwt *+
    decfsz  WREG, F
    bra     Lp1
    tblrd   *-                ; Point back into the block
    movlw   b'10000100'       ; Setup writes
    movwf   EECON1
    rcall   StartWrite        ; Write the data
    tblrd   *+                ; Point to the beginning of the next block
    decfsz  COUNTER, F
    bra     WriteProgMem      ; Not finished then repeat
    bra     SendAcknowledge   ; Send acknowledge

; In: <STX><STX>[<0x03><DLENROW><ADDRL><ADDRH><ADDRL>]<CHKSUM><ETX>
; OUT: <STX><STX>[<0x03>]<CHKSUM><ETX>

EraseProgMem
    movlw   b'10010100'       ; Setup writes
    movwf   EECON1
    rcall   StartWrite        ; Erase the row
    movlw   0x40                ; Point to next row
    addwf   TBLPTRL, F
    clrf    WREG
    addwfc  TBLPTRH, F
    addwfc  TBLPTRU, F
    decfsz  COUNTER, F
    bra     EraseProgMem
    bra     SendAcknowledge   ; Send acknowledge

; In: <STX><STX>[<0x04><DLEN><ADDRL><ADDRH><0x00>]<CHKSUM><ETX>
; OUT: <STX><STX>[<0x04><DLEN><ADDRL><ADDRH><0x00><DATA>...]<CHKSUM><ETX>

ReadEE
    clrf    EECON1
    bsf     EECON1, RD        ; Read the data
    movff   EECON1, POSTINC0
    infsnz  EEADR, F; Adjust EECON1 pointer
    incf    EEADR, F
    decfsz  COUNTER, F
    bra     ReadEE           ; Not finished then repeat
    movf    DATA_COUNT, W    ; Setup packet length
    addlw   0x05
    bra     WritePacket

; In:  <STX><STX>[<0x05><DLEN><ADDRL><ADDRH><0x00><DATA>...]<CHKSUM><ETX>
; OUT: <STX><STX>[<0x05>]<CHKSUM><ETX>
```

```

WriteEE
    movff  POSTINC0, EEDATA
    rcall  WriteWaitEEData          ; Write data
    infsnz EEADR, F                 ; Adjust EEDATA pointer
    incf   EEADRH, F
    decfsz COUNTER, F
    bra    WriteEE                  ; Not finished then repeat
    bra    SendAcknowledge          ; Send acknowledge

; In:  <STX><STX>[<0x06><DLEN><ADDRL><ADDRH><ADDRU>]<CHKSUM><ETX>
; OUT: <STX><STX>[<0x06><DLEN><ADDRL><ADDRH><ADDRU><DATA>...]<CHKSUM><ETX>

;ReadConfig
;   movlw  b'11000000'
;   movwf  EECON1
;
;Lp5
    tblrd*+
;   movff  TABLAT, POSTINC0
;   decfsz COUNTER, F
;   bra    Lp5                      ; Not finished then repeat
;   movf   DATA_COUNT, W          ; Setup packet length
;   addlw  0x05
;   bra    WritePacket

; In:  <STX><STX>[<0x07><DLEN><ADDRL><ADDRH><ADDRU><DATA>...]<CHKSUM><ETX>
; OUT: <STX><STX>[<0x07>]<CHKSUM><ETX>

WriteConfig
    movlw  b'11000100'
    movwf  EECON1
    movff  POSTINC0, TABLAT        ; Write to config area
    tblwt  *
    rcall  StartWrite
    tblrd  *+
    decfsz COUNTER, F
    bra    WriteConfig            ; Not finished then repeat
    bra    SendAcknowledge        ; Send acknowledge
; *****

; *****
; Send the data buffer back.
;
; <STX><STX>[<DATA>...]<CHKSUM><ETX>

SendAcknowledge
    movlw  0x01                    ; Send acknowledge

WritePacket
    movwf  COUNTER
    movlw  STX                      ; Send start condition
    rcall  WrRS232
    rcall  WrRS232
    clrf   CHKSUM                    ; Reset checksum
    lfsr   FSR0, DATA_BUFF          ; Setup pointer to buffer area

SendNext
    movf   POSTINC0, W
    addwf  CHKSUM
    rcall  WrData
    decfsz COUNTER, F
    bra    SendNext
    negf   CHKSUM                    ; Send checksum
    movf   CHKSUM, W
    rcall  WrData

```

AN851

```
    movlw    ETX                                ; Send stop condition
    rcall   WrRS232
    bra     Autobaud
; *****

; *****
; Write a byte to the serial port.
WrData
    movwf   TXDATA                            ; Save the data
    xorlw   STX                               ; Check for a STX
    bz     WrDLE                               ; No, continue WrNext
    movf   TXDATA, W
    xorlw   ETX                               ; Check for a ETX
    bz     WrDLE                               ; No, continue WrNext
    movf   TXDATA, W
    xorlw   DLE                               ; Check for a DLE
    bnz    WrNext                             ; No, continue WrNext
WrDLE
    movlw   DLE                               ; Yes, send DLE first
    rcall   WrRS232
WrNext
    movf   TXDATA, W                          ; Then send STX
WrRS232
    clrwdt
    btfss  PIR1, TXIF                          ; Write only if TXREG is ready
    bra    $ - 2
    movwf  TXREG1                              ; Start sending
    return
; *****

; *****
RdRS232
    clrwdt
    btfsc  RCSTA1, OERR                        ; Reset on overrun
    reset
    btfss  PIR1, RCIF                          ; Wait for data from RS232
    bra    $ - 2
    movf   RCREG1, W                          ; Save the data
    movwf  RXDATA
    return
; *****

; *****
BootMode
    setf   EEADR                               ; Point to the last byte
    setf   EEADRH
    setf   EEDATA                              ; Bootmode control byte
    rcall  WriteWaitEEData
    reset
; *****

; *****
WaitForRise
    btfsc  PORTC, 7                            ; Wait for a falling edge
    bra    WaitForRise
    clrwdt
```

```

WtSR
    btfss    PORTC, 7                ; Wait for starting edge
    bra     WtSR
    return
; *****

; *****
; Unlock and start the write or erase sequence.

StartWrite
    clrwdt
    movlw   0x55                    ; Unlock
    movwf   EECON2
    movlw   0xAA
    movwf   EECON2
    bsf     EECON1, WR              ; Start the write
    nop
    return
; *****

; *****
    ORG 0x000A

WriteWaitEEData
    movlw   b'00000100'            ; Setup for EEData
    movwf   EECON1
    rcall   StartWrite
    btfsc   EECON1, WR              ; Write and wait
    bra     $ - 2
    return
; *****

; *****
    ORG    0x200
RVReset

    ORG    0x208
RVIntH

    ORG    0x218
RVIntL
; *****

    END

```

AN851

C.2 PIC16F87XA Bootloader Firmware

```
; Bootloader for PIC16F by Rodger Richey
; Adapted from PIC18F bootloader developed by Ross Fosler
; 03/18/2002 First full implementation
; 03/25/2002 Modified receive & parse engine to vector to autobaud on a checksum
; error since a checksum error could likely be a communications problem.
; Modified the protocol to incorporate the autobaud as part of the
; first received <STX>. Doing this improves robustness by allowing
; re-sync under any condition. Previously it was possible to enter a
; state where only a hard reset would allow re-syncing.
; 04/09/2002 Fixed bugs: 1) clear carry before shifting ABTIME in Autobaud
; 2) Increment address in program memory write
; 3) Increment address in program memory read
; 06/07/2002 Fixed bug in read, byte counter in code is word counter.
; Needed to multiply by 2 to get bytes.
```

```
; Memory Map
```

```
; -----
```

0x0000	Reset vector
0x0004	Interrupt vector
Boot Block	(this program)
0x0100	Re-mapped Reset Vector
0x0104	Re-mapped High Priority Interrupt Vector
Code Space	User program space
0x3FFF	

```
; -----
```

```
; Incoming data format:
```

```
; <STX><STX><DATA><CHKSUM><ETX>
; / \
; / \
; / \
; <COMMAND><DLEN><ADDRL><ADDRH><ADDRU><DATA>...
```

```
; Definitions:
```

```
; STX - Start of packet indicator
; ETX - End of packet indicator
; LEN - Length of incoming packet
; DATA - General data up to 255 bytes
; CHKSUM - The 8-bit two's compliment sum of LEN & DATA
; COMMAND - Base command
; DLEN - Length of data associated to the command
; ADDR - Address up to 24 bits
; DATA - Data (if any)
```

```
; Commands:
```

```
; RD_VER 0x00 Read Version Information
; RD_MEM 0x01 Read Program Memory
; WR_MEM 0x02 Write Program Memory
; ER_MEM 0x03 Erase Program Memory (NOT supported by PIC16)
```



```

; RD_EE      0x04   Read EEDATA Memory
; WR_EE      0x05   Write EEDATA Memory
; RD_CONFIG  0x06   Read Config Memory (NOT supported by PIC16)
; WT_CONFIG  0x07   Write Config Memory (NOT supported by PIC16)
;
; *****

; *****
; #include P16F877A.INC; Standard include
; *****

errorlevel -302; Do not show any banking warnings

; *****
#define MINOR_VERSION 0x03      ; Version
#define MAJOR_VERSION 0x00

#define RC_DLE 0x01
#define RC_STX 0x02

#define STX    0x0F
#define ETX    0x04
#define DLE    0x05

;#define DEBUGGING              ; Debugging enabled with ICD
; *****

; *****
CHKSUM      equ 0x71           ; Checksum accumulator
COUNTER     equ 0x72           ; General counter
ABTIME      equ 0x73
RXDATA      equ 0x74
TXDATA      equ 0x75
TEMP        equ 0x76

PCLATH_TEMP equ 0x7D           ; Interrupt context
STATUS_TEMP equ 0x7E           ; save/restore registers
W_TEMP      equ 0x7F

; Frame Format
;
; <STX><STX>[<COMMAND><DATALEN><ADDRL><ADDRH><ADDRU><...DATA...>]<CHKSUM><ETX>

DATA_BUFFequ0x10; Start of receive buffer

COMMAND     equ 0x10           ; Data mapped in receive buffer
DATA_COUNT  equ 0x11
ADDRESS_L   equ 0x12
ADDRESS_H   equ 0x13
ADDRESS_U   equ 0x14
PACKET_DATA equ 0x15
; *****

; *****
ORG 0x0000           ; Re-map Reset vector
VReset
    bcf    STATUS,RP0
    bsf    STATUS,RP1
    clrf   PCLATH

```

AN851

```
    goto    Setup
    ORG 0x0004
VInt
    movwf   W_TEMP
    swapf   STATUS,W
    movwf   STATUS_TEMP
    clrf    STATUS
    movf    PCLATH,W
    movwf   PCLATH_TEMP
    clrf    PCLATH
    goto    RVInt                                ; Re-map Interrupt vector
; *****

; *****
; Set up the appropriate registers.
Setup
    clrwdt
    movlw   0xFF
    movwf   EEADR                                ; Point to last location
    bsf     STATUS,RP0
    clrf    EECON1
    bsf     EECON1,RD                            ; Read the control code
    bcf     STATUS,RP0
    incf    EEDATA,W
    btfsc   STATUS,Z
    goto    SRX
    bcf     STATUS,RP1
    goto    RVReset                              ; If not 0xFF then normal reset
SRX
    bcf     STATUS,RP1
    movlw   b'10000000'                          ; Setup rx and tx, CREN disabled;
    movwf   RCSTA
    bsf     STATUS,RP0
    bcf     TRISC,6                              ; Setup tx pin
    movlw   b'00100110'
    movwf   TXSTA
    bsf     STATUS,IRP
; *****

; *****
Autobaud
;
; _____
;  \_____/ \_____/ \_____/
;  |         |         |
;  |----- p -----|
;
; p = The number of instructions between the first and last
;      rising edge of the RS232 control sequence 0x0F. Other
;      possible control sequences are 0x01, 0x03, 0x07, 0x1F,
;      0x3F, 0x7F.
;
; SPBRG = (p / 32) - 1  BRGH = 1

    bcf     STATUS,RP1
    bsf     STATUS,RP0
    movlw   b'00000011'
    movwf   OPTION_REG
    bcf     STATUS,RP0
    bcf     RCSTA,CREN
    call    WaitForRise
```

```

    clrf    TMR0                ; Start counting
    call   WaitForRise
    movf   TMR0,W              ; Read the timer
    movwf  ABTIME
    bcf    STATUS,C
    rrf    ABTIME,W
    btfss  STATUS,C            ; Rounding
    addlw  0xFF
    bsf    STATUS,RP0
    movwf  SPBRG
    bcf    STATUS,RP0
    bsf    RCSTA,CREN          ; Enable receive
    movf   RCREG,W
    movf   RCREG,W
    bsf    STATUS,RP0
    movlw  b'11111111'
    movwf  OPTION_REG
; *****

; *****
; Read and parse the data.
StartOfLine
    bcf    STATUS,RP0
    bcf    STATUS,RP1
    call   RdRS232             ; Look for a start of line
    xorlw  STX                 ; <STX><STX>
    btfss  STATUS,Z
    goto   Autobaud           ; was StartOfLine
    movlw  DATA_BUFFER       ; Point to the buffer
    movwf  FSR
    clrf   CHKSUM              ; Reset checksum
GetNextDat
    call   RdRS232             ; Get the data
    xorlw  STX                 ; Check for a STX
    btfsc  STATUS,Z
    goto   StartOfLine        ; Yes, start over
NoSTX
    movf   RXDATA,W
    xorlw  ETX                 ; Check for a ETX
    btfsc  STATUS,Z
    goto   CheckSum           ; Yes, examine checksum
NoETX
    movf   RXDATA,W
    xorlw  DLE                 ; Check for a DLE
    btfss  STATUS,Z
    goto   NoDLE              ; Check for a DLE
    call   RdRS232            ; Yes, Get the next byte
NoDLE
    movf   RXDATA,W
    movwf  INDF                ; Store the data
    addwf  CHKSUM,F            ; Get sum
    incf   FSR,F
    goto   GetNextDat
CheckSum
    movf   CHKSUM,F            ; Checksum test
    btfss  STATUS,Z
    goto   Autobaud
; *****

```

AN851

```
; *****
; Pre-setup, common to all commands.
    bsf     STATUS,RP1
    movf   ADDRESS_L,W           ; Set all possible pointers
    movwf  EEADR
    movf   ADDRESS_H,W
    movwf  EEADRH
    movlw  PACKET_DATA
    movwf  FSR
    movf   DATA_COUNT,W        ; Setup counter
    movwf  COUNTER
    btfsc  STATUS,Z
    goto   VReset               ; Non valid count (Special Command)
; *****

; *****
; Test the command field and sub-command.
CheckCommand
    movf   COMMAND,W           ; Test for a valid command
    sublw  d'7'
    btfss  STATUS,C
    goto   Autobaud
    movf   COMMAND,W           ; Perform calculated jump
    addwf  PCL,F
    goto   ReadVersion         ; 0
    goto   ReadProgMem         ; 1
    goto   WriteProgMem        ; 2
    goto   StartOfLine         ; 3
    goto   ReadEE              ; 4
    goto   WriteEE             ; 5
    goto   StartOfLine         ; 6
    goto   StartOfLine         ; 7
; maybe add jump to reset vector in this table
; *****

; *****
; Commands
;
; In:  <STX><STX>[<0x00><0x02>]<0xFF><ETX>
; OUT: <STX><STX>[<0x00><VERL><VERH>]<CHKSUM><ETX>
ReadVersion
    movlw  MINOR_VERSION
    movwf  DATA_BUFF + 2
    movlw  MAJOR_VERSION
    movwf  DATA_BUFF + 3
    movlw  0x04
    goto   WritePacket

; In:  <STX><STX>[<0x01><DLEN><ADDRL><ADDRH><ADDRU>]<CHKSUM><ETX>
; OUT: <STX><STX>[<0x01><DLEN><ADDRL><ADDRH><ADDRU><DATA>...]<CHKSUM><ETX>
ReadProgMem
RPM1
    bsf     STATUS,RP0
    bsf     EECON1,EEPGD
    bsf     EECON1,RD
    nop
    nop
    bcf     STATUS,RP0
    movf   EEDATA,W
    movwf  INDF
```

```

incf    FSR,F
movf    EEDATH,W
movwf   INDF
incf    FSR,F
incf    EEADR,F
btfsc   STATUS,Z
incf    EEADRH,F
decfsz  COUNTER,F
goto    RPM1                ; Not finished then repeat
rlf     DATA_COUNT,W      ; Setup packet length
addlw   0x05
goto    WritePacket

; In:   <STX><STX>[<0x02><DLENBLOCK><ADDRL><ADDRH><ADDRU><DATA>...]<CHKSUM><ETX>
; OUT:  <STX><STX>[<0x02>]<CHKSUM><ETX>

WriteProgMem
    bsf    STATUS,RP0
    movlw  b'10000100'      ; Setup writes
    movwf  EECON1
    bcf    STATUS,RP0
    movlw  b'11111100'      ; Force a boundary
    andwf  EEADR,F
    movlw  0x04
    movwf  TEMP

Lp1
    movf   INDF,W
    movwf  EEDATA
    incf   FSR,F
    movf   INDF,W
    movwf  EEDATH
    incf   FSR,F
    call   StartWrite
    incf   EEADR,F
    btfsc  STATUS,Z
    incf   EEADRH,F
    decfsz TEMP,F
    goto   Lp1
    decfsz COUNTER,F
    goto   WriteProgMem      ; Not finished then repeat
    goto   SendAcknowledge   ; Send acknowledge

; In:   <STX><STX>[<0x04><DLEN><ADDRL><ADDRH><0x00>]<CHKSUM><ETX>
; OUT:  <STX><STX>[<0x04><DLEN><ADDRL><ADDRH><0x00><DATA>...]<CHKSUM><ETX>

ReadEE
    bsf    STATUS,RP0
    clrf   EECON1
    bsf    EECON1,RD        ; Read the data
    bcf    STATUS,RP0
    movf   EEDATA,W
    movwf  INDF
    incf   FSR,F
    incf   EEADR,F          ; Adjust EEDATA pointer
    decfsz COUNTER,F
    goto   ReadEE          ; Not finished then repeat
    movf   DATA_COUNT,W   ; Setup packet length
    addlw  0x05
    goto   WritePacket

; IN:   <STX><STX>[<0x05><DLEN><ADDRL><ADDRH><0x00><DATA>...]<CHKSUM><ETX>
; OUT:  <STX><STX>[<0x05>]<CHKSUM><ETX>

```

AN851

```
WriteEE
    movf    INDF,W
    movwf   EEDATA
    incf    FSR,F
    call    WriteWaitEEData          ; Write data
    incf    EEADR,F                  ; Adjust EEDATA pointer
    decfsz COUNTER,F
    goto    WriteEE                  ; Not finished then repeat
    goto    SendAcknowledge          ; Send acknowledge
; *****

; *****
; Send the data buffer back.
;
; <STX><STX>[<DATA>...]<CHKSUM><ETX>

SendAcknowledge
    movlw   0x01                    ; Send acknowledge
WritePacket
    movwf   COUNTER
    movlw   STX                      ; Send start condition
    call    WrRS232
    call    WrRS232
    clrf    CHKSUM                    ; Reset checksum
    movlw   DATA_BUFF              ; Setup pointer to buffer area
    movwf   FSR
SendNext
                                        ; Send DATA
    movf    INDF,W
    addwf   CHKSUM,F
    incf    FSR,F
    call    WrData
    decfsz COUNTER,F
    goto    SendNext
    comf    CHKSUM,W                  ; Send checksum
    addlw   0x01
    call    WrData
    movlw   ETX                      ; Send stop condition
    call    WrRS232
    goto    Autobaud
; *****

; *****
; Write a byte to the serial port.

WrData
    movwf   TXDATA                    ; Save the data
    xorlw   STX                      ; Check for a STX
    btfsc   STATUS,Z
    goto    WrDLE                      ; No, continue WrNext
    movf    TXDATA,W
    xorlw   ETX                      ; Check for a ETX
    btfsc   STATUS,Z
    goto    WrDLE                      ; No, continue WrNext
    movf    TXDATA,W
    xorlw   DLE                      ; Check for a DLE
    btfss   STATUS,Z
    goto    WrNext                      ; No, continue WrNext
WrDLE
    movlw   DLE                      ; Yes, send DLE first
    call    WrRS232
```

```
WrNext
  movf    TXDATA,W          ; Then send STX; DC
WrRS232
  clrwdt
  bcf     STATUS,RP1
  btfss  PIR1,TXIF         ; Write only if TXREG is ready
  goto   $ - 1
  movwf  TXREG             ; Start sending
  return
; *****

; *****

RdRS232
  clrwdt
  btfsc  RCSTA,OERR        ; Reset on overrun
  goto   VReset
  btfss  PIR1,RCIF         ; Wait for data from RS232
  goto   $ - 1
  movf   RCREG,W           ; Save the data
  movwf  RXDATA
  return
; *****

; *****

WaitForRise
  btfsc  PORTC,7           ; Wait for a falling edge
  goto   WaitForRise
  clrwdt                    ; Do we need this?
WtSR
  btfss  PORTC,7           ; Wait for starting edge
  goto   WtSR
  return
; *****

; *****
; Unlock and start the write or erase sequence.

StartWrite
  clrwdt
  bsf    STATUS,RP0
  movlw  0x55              ; Unlock
  movwf  EECON2
  movlw  0xAA
  movwf  EECON2
  bsf    EECON1,WR        ; Start the write
  nop
  nop
  bcf    STATUS,RP0
  return
; *****
```

AN851

```
; *****
WriteWaitEEData
    bsf     STATUS,RP0
    movlw  b'00000100'           ; Setup for EEData
    movwf  EECON1
    call   StartWrite
    btfsc  EECON1,WR           ; Write and wait
    goto   $ - 1
    bcf    STATUS,RP0
    return
; *****
; *****
    ORG 0x100
RVReset

    ORG 0x104
RVInt

; *****

    END
```


APPENDIX D: LINKER SCRIPT EXAMPLES

D.1 Assembly Linker Script for PIC18F452

```
// Linker command file for 18F452 with bootloader
// By R. Fosler

LIBPATH .

CODEPAGE NAME=boot START=0x0 END=0x1FF PROTECTED
CODEPAGE NAME=prog START=0x200 END=0x7FFF
CODEPAGE NAME=idlocs START=0x200000 END=0x200007 PROTECTED
CODEPAGE NAME=config START=0x300000 END=0x30000D PROTECTED
CODEPAGE NAME=devid START=0x3FFFFE END=0x3FFFFF PROTECTED
CODEPAGE NAME=eedata START=0xF00000 END=0xF000FF PROTECTED

ACCESSBANK NAME=accessram START=0x0 END=0x7F
DATABANK NAME=gpr0 START=0x80 END=0xFF
DATABANK NAME=gpr1 START=0x100 END=0x1FF
DATABANK NAME=gpr2 START=0x200 END=0x2FF
DATABANK NAME=gpr3 START=0x300 END=0x3FF
DATABANK NAME=gpr4 START=0x400 END=0x4FF
DATABANK NAME=gpr5 START=0x500 END=0x5FF
ACCESSBANK NAME=accesssfr START=0xF80 END=0xFFF PROTECTED
```

D.2 C18 Linker Script

```
// Sample linker command file for 18F452 with Bootloader
// Ross M. Fosler, 03/27/2002

LIBPATH .

FILES c018i.o
FILES clib.lib
FILES p18f452.lib

CODEPAGE NAME=boot START=0x0 END=0x1FF PROTECTED
CODEPAGE NAME=vectors START=0x200 END=0x229 PROTECTED
CODEPAGE NAME=page START=0x22A END=0x7FFF
CODEPAGE NAME=idlocs START=0x200000 END=0x200007 PROTECTED
CODEPAGE NAME=config START=0x300000 END=0x30000D PROTECTED
CODEPAGE NAME=devid START=0x3FFFFE END=0x3FFFFF PROTECTED
CODEPAGE NAME=eedata START=0xF00000 END=0xF000FF PROTECTED

ACCESSBANK NAME=accessram START=0x0 END=0x7F
DATABANK NAME=gpr0 START=0x80 END=0xFF
DATABANK NAME=gpr1 START=0x100 END=0x1FF
DATABANK NAME=gpr2 START=0x200 END=0x2FF
DATABANK NAME=gpr3 START=0x300 END=0x3FF
DATABANK NAME=gpr4 START=0x400 END=0x4FF
DATABANK NAME=gpr5 START=0x500 END=0x5FF
ACCESSBANK NAME=accesssfr START=0xF80 END=0xFFF PROTECTED

STACK SIZE=0x100 RAM=gpr5
```

AN851

D.3 Assembly Linker Script for PIC16F877A

```
// Sample linker command file for 16F877a and 876a
// $Id: 16f877a.lkr,v 1.1.2.2 2001/09/20 19:48:40 ConnerJ Exp $
// modified 2002/06/14 for bootloader RicheyR

LIBPATH .

CODEPAGE    NAME=boot      START=0x0000    END=0x00FF    PROTECTED
CODEPAGE    NAME=page0    START=0x0100    END=0x07FF
CODEPAGE    NAME=page1    START=0x0800    END=0x0FFF
CODEPAGE    NAME=page2    START=0x1000    END=0x17FF
CODEPAGE    NAME=page3    START=0x1800    END=0x1FFF
CODEPAGE    NAME=.idlocs  START=0x2000    END=0x2003    PROTECTED
CODEPAGE    NAME=.config  START=0x2007    END=0x2007    PROTECTED
CODEPAGE    NAME=eedata   START=0x2100    END=0x21FF    PROTECTED

DATABANK    NAME=sfr0     START=0x0       END=0x1F      PROTECTED
DATABANK    NAME=sfr1     START=0x80      END=0x9F      PROTECTED
DATABANK    NAME=sfr2     START=0x100     END=0x10F     PROTECTED
DATABANK    NAME=sfr3     START=0x180     END=0x18F     PROTECTED

DATABANK    NAME=gpr0     START=0x20      END=0x6F
DATABANK    NAME=gpr1     START=0xA0      END=0xEF
DATABANK    NAME=gpr2     START=0x110    END=0x16F
DATABANK    NAME=gpr3     START=0x190    END=0x1EF

SHAREBANK   NAME=gprnobnk START=0x70      END=0x7F
SHAREBANK   NAME=gprnobnk START=0xF0      END=0xFF
SHAREBANK   NAME=gprnobnk START=0x170     END=0x17F
SHAREBANK   NAME=gprnobnk START=0x1F0     END=0x1FF

SECTION     NAME=STARTUP  ROM=boot        // Reset, interrupt vectors, bootloader
SECTION     NAME=PROG1    ROM=page0       // ROM code space - page0
SECTION     NAME=PROG2    ROM=page1       // ROM code space - page1
SECTION     NAME=PROG3    ROM=page2       // ROM code space - page2
SECTION     NAME=PROG4    ROM=page3       // ROM code space - page3
SECTION     NAME=IDLOCS  ROM=.idlocs     // ID locations
SECTION     NAME=CONFIG   ROM=.config     // Configuration bits location
SECTION     NAME=DEEPROM  ROM=eedata      // Data EEPROM
```

APPENDIX E: SOFTWARE DISCUSSED IN THIS APPLICATION NOTE

All of the software covered in this application note (the PIC16/PIC18 Quick Programmer, the source code for the bootloaders and associated project files) are available as a single WinZip archive file. The archive may be downloaded from the Microchip corporate web site at:

www.microchip.com

AN851

NOTES:

Note the following details of the code protection feature on PICmicro® MCUs.

- The PICmicro family meets the specifications contained in the Microchip Data Sheet.
- Microchip believes that its family of PICmicro microcontrollers is one of the most secure products of its kind on the market today, when used in the intended manner and under normal conditions.
- There are dishonest and possibly illegal methods used to breach the code protection feature. All of these methods, to our knowledge, require using the PICmicro microcontroller in a manner outside the operating specifications contained in the data sheet. The person doing so may be engaged in theft of intellectual property.
- Microchip is willing to work with the customer who is concerned about the integrity of their code.
- Neither Microchip nor any other semiconductor manufacturer can guarantee the security of their code. Code protection does not mean that we are guaranteeing the product as “unbreakable”.
- Code protection is constantly evolving. We at Microchip are committed to continuously improving the code protection features of our product.

If you have any further questions about this matter, please contact the local sales office nearest to you.

Information contained in this publication regarding device applications and the like is intended through suggestion only and may be superseded by updates. It is your responsibility to ensure that your application meets with your specifications. No representation or warranty is given and no liability is assumed by Microchip Technology Incorporated with respect to the accuracy or use of such information, or infringement of patents or other intellectual property rights arising from such use or otherwise. Use of Microchip's products as critical components in life support systems is not authorized except with express written approval by Microchip. No licenses are conveyed, implicitly or otherwise, under any intellectual property rights.

Trademarks

The Microchip name and logo, the Microchip logo, KEELOQ, MPLAB, PIC, PICmicro, PICSTART and PRO MATE are registered trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.


FilterLab, microID, MXDEV, MXLAB, PICMASTER, SEEVAL and The Embedded Control Solutions Company are registered trademarks of Microchip Technology Incorporated in the U.S.A.


dsPIC, dsPICDEM.net, ECONOMONITOR, FanSense, FlexROM, fuzzyLAB, In-Circuit Serial Programming, ICSP, ICEPIC, microPort, Migratable Memory, MPASM, MPLIB, MPLINK, MPSIM, PICC, PICDEM, PICDEM.net, rPIC, Select Mode and Total Endurance are trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

Serialized Quick Turn Programming (SQTP) is a service mark of Microchip Technology Incorporated in the U.S.A.

All other trademarks mentioned herein are property of their respective companies.

© 2002, Microchip Technology Incorporated, Printed in the U.S.A., All Rights Reserved.

 Printed on recycled paper.



Microchip received QS-9000 quality system certification for its worldwide headquarters, design and wafer fabrication facilities in Chandler and Tempe, Arizona in July 1999 and Mountain View, California in March 2002. The Company's quality system processes and procedures are QS-9000 compliant for its PICmicro® 8-bit MCUs, KEELOQ® code hopping devices, Serial EEPROMs, microperipherals, non-volatile memory and analog products. In addition, Microchip's quality system for the design and manufacture of development systems is ISO 9001 certified.



MICROCHIP

WORLDWIDE SALES AND SERVICE

AMERICAS

Corporate Office

2355 West Chandler Blvd.
Chandler, AZ 85224-6199
Tel: 480-792-7200 Fax: 480-792-7277
Technical Support: 480-792-7627
Web Address: <http://www.microchip.com>

Rocky Mountain

2355 West Chandler Blvd.
Chandler, AZ 85224-6199
Tel: 480-792-7966 Fax: 480-792-4338

Atlanta

500 Sugar Mill Road, Suite 200B
Atlanta, GA 30350
Tel: 770-640-0034 Fax: 770-640-0307

Boston

2 Lan Drive, Suite 120
Westford, MA 01886
Tel: 978-692-3848 Fax: 978-692-3821

Chicago

333 Pierce Road, Suite 180
Itasca, IL 60143
Tel: 630-285-0071 Fax: 630-285-0075

Dallas

4570 Westgrove Drive, Suite 160
Addison, TX 75001
Tel: 972-818-7423 Fax: 972-818-2924

Detroit

Tri-Atria Office Building
32255 Northwestern Highway, Suite 190
Farmington Hills, MI 48334
Tel: 248-538-2250 Fax: 248-538-2260

Kokomo

2767 S. Albright Road
Kokomo, Indiana 46902
Tel: 765-864-8360 Fax: 765-864-8387

Los Angeles

18201 Von Karman, Suite 1090
Irvine, CA 92612
Tel: 949-263-1888 Fax: 949-263-1338

New York

150 Motor Parkway, Suite 202
Hauppauge, NY 11788
Tel: 631-273-5305 Fax: 631-273-5335

San Jose

Microchip Technology Inc.
2107 North First Street, Suite 590
San Jose, CA 95131
Tel: 408-436-7950 Fax: 408-436-7955

Toronto

6285 Northam Drive, Suite 108
Mississauga, Ontario L4V 1X5, Canada
Tel: 905-673-0699 Fax: 905-673-6509

ASIA/PACIFIC

Australia

Microchip Technology Australia Pty Ltd
Suite 22, 41 Rawson Street
Epping 2121, NSW
Australia
Tel: 61-2-9868-6733 Fax: 61-2-9868-6755

China - Beijing

Microchip Technology Consulting (Shanghai)
Co., Ltd., Beijing Liaison Office
Unit 915
Bei Hai Wan Tai Bldg.
No. 6 Chaoyangmen Beidajie
Beijing, 100027, No. China
Tel: 86-10-85282100 Fax: 86-10-85282104

China - Chengdu

Microchip Technology Consulting (Shanghai)
Co., Ltd., Chengdu Liaison Office
Rm. 2401, 24th Floor,
Ming Xing Financial Tower
No. 88 TIDU Street
Chengdu 610016, China
Tel: 86-28-86766200 Fax: 86-28-86766599

China - Fuzhou

Microchip Technology Consulting (Shanghai)
Co., Ltd., Fuzhou Liaison Office
Unit 28F, World Trade Plaza
No. 71 Wusi Road
Fuzhou 350001, China
Tel: 86-591-7503506 Fax: 86-591-7503521

China - Shanghai

Microchip Technology Consulting (Shanghai)
Co., Ltd.
Room 701, Bldg. B
Far East International Plaza
No. 317 Xian Xia Road
Shanghai, 200051
Tel: 86-21-6275-5700 Fax: 86-21-6275-5060

China - Shenzhen

Microchip Technology Consulting (Shanghai)
Co., Ltd., Shenzhen Liaison Office
Rm. 1315, 13/F, Shenzhen Kerry Centre,
Renminnan Lu
Shenzhen 518001, China
Tel: 86-755-82350361 Fax: 86-755-82366086

China - Hong Kong SAR

Microchip Technology Hongkong Ltd.
Unit 901-6, Tower 2, Metroplaza
223 Hing Fong Road
Kwai Fong, N.T., Hong Kong
Tel: 852-2401-1200 Fax: 852-2401-3431

India

Microchip Technology Inc.
India Liaison Office
Divyasree Chambers
1 Floor, Wing A (A3/A4)
No. 11, O'Shaughnessy Road
Bangalore, 560 025, India
Tel: 91-80-2290061 Fax: 91-80-2290062

Japan

Microchip Technology Japan K.K.
Benex S-1 6F
3-18-20, Shinyokohama
Kohoku-Ku, Yokohama-shi
Kanagawa, 222-0033, Japan
Tel: 81-45-471-6166 Fax: 81-45-471-6122

Korea

Microchip Technology Korea
168-1, Youngbo Bldg. 3 Floor
Samsung-Dong, Kangnam-Ku
Seoul, Korea 135-882
Tel: 82-2-554-7200 Fax: 82-2-558-5934

Singapore

Microchip Technology Singapore Pte Ltd.
200 Middle Road
#07-02 Prime Centre
Singapore, 188980
Tel: 65-6334-8870 Fax: 65-6334-8850

Taiwan

Microchip Technology (Barbados) Inc.,
Taiwan Branch
11F-3, No. 207
Tung Hua North Road
Taipei, 105, Taiwan
Tel: 886-2-2717-7175 Fax: 886-2-2545-0139

EUROPE

Austria

Microchip Technology Austria GmbH
Durisolstrasse 2
A-4600 Wels
Austria
Tel: 43-7242-2244-399
Fax: 43-7242-2244-393

Denmark

Microchip Technology Nordic ApS
Regus Business Centre
Lautrup høj 1-3
Ballerup DK-2750 Denmark
Tel: 45 4420 9895 Fax: 45 4420 9910

France

Microchip Technology SARL
Parc d'Activite du Moulin de Massy
43 Rue du Saule Trapu
Batiment A - 1er Etage
91300 Massy, France
Tel: 33-1-69-53-63-20 Fax: 33-1-69-30-90-79

Germany

Microchip Technology GmbH
Steinheilstrasse 10
D-85737 Ismaning, Germany
Tel: 49-89-627-144 0 Fax: 49-89-627-144-44

Italy

Microchip Technology SRL
Centro Direzionale Colleoni
Palazzo Taurus 1 V. Le Colleoni 1
20041 Agrate Brianza
Milan, Italy
Tel: 39-039-65791-1 Fax: 39-039-6899883

United Kingdom

Microchip Ltd.
505 Eskdale Road
Winnesh Triangle
Wokingham
Berkshire, England RG41 5TU
Tel: 44 118 921 5869 Fax: 44-118 921-5820

08/01/02